



K-AD8101 User manual
Version: V100

- Precautions
 1. Please read the instruction manual carefully before use.
 2. This product is not a toy and is not suitable for children under 14 years of age.
 3. Do not change the product parts to avoid damage.
 4. Do not place conductive materials on the surface of the product.
 5. Make sure to connect the correct turnout motor after setting the turnout output to avoid damage to the decoder or turnout motor.

- Features
 1. K-AD200, K-AD400, K-AD800 connect the output to an external power supply to drive the Turnout motor.
 2. Can be connected to 3-wire turnout motor. Cannot be used for 2-wire turnout motor.
 3. It is recommended to use DC 12~16V 3A or more for the power supply.

- Connection Diagram

